

# Ford / Version: 9.6.3

## Legend

Existing Function

Currently Under Development

Functionality doesn't apply

4X4				
Sistema	DTC	Flujo de Datos	Actuadores	Config
4 X 4 - 2V MOUNTAINEER/EXPLORER 4.6L (PETROL)				
4 X 4 (RANGER)				
4x4 (F-SERIES 3.9L Cummins Diesel)				
ABS - ANTI LOCK BRAKE MODULE				
Sistema	DTC	Flujo de Datos	Actuadores	Config
ABS - FIESTA MK IV				
<i>Special Functions</i>				
Sistema	DTC	Flujo de Datos	Actuadores	Config
ABS - FOCUS 1.8L (DURATORQ TDCI / ZETEC)				
ABS - GALAXY/SMAX/MONDEO MY08				
<i>Special Functions</i>				
<i>Configure the lateral acceleration sensor.</i>				
<i>Configure the longitudinal acceleration sensor.</i>				
<i>Configure the steering angle sensor.</i>				
<i>Configure the yaw rate sensor.</i>				
<i>Pressure Sensor Calibration</i>				
Sistema	DTC	Flujo de Datos	Actuadores	Config
ABS - I4 DSL ELECTRONIC 3.0L (RANGER)				
<i>Special Functions</i>				
<i>Programmable Module Installation</i>				
Sistema	DTC	Flujo de Datos	Actuadores	Config
ABS - KA 1.0L ZETEC ROCAM				
ABS - Mazda				
ABS - MONDEO (ZETEC 1.8L)				
ABS - PUMA				
ABS - TRANSIT /TOURNEO CONNECT				
ABS (CONTOUR/MISTYQUE)				
ABS (FIESTA-FOCUS) (DURATEC 16V)				
ABS (F-SERIES 3.9L Cummins Diesel)				
ABS (F-SERIES SUPER DUTY)				
ABS (KA 1.3 / 1.6L DURATEC 8V)				
ABS Explorer				
ABS FIESTA / FUSION / ECO SPORT				
ABS FOCUS (CAN)				
<i>Special Functions</i>				
<i>ABS Service Bleed</i>				
<i>Auxiliary vehicle ID reset</i>				
<i>Programmable Module Installation</i>				

Sistema	DTC	Flujo de Datos	Actuadores	Config
ABS FOCUS (CAN)	✓	✓		
ABS FOCUS C-MAX	✓	✓	✓	✓
<i>Special Functions</i>				
<i>Programmable Module Installation</i>				

Sistema	DTC	Flujo de Datos	Actuadores	Config
ABS MONDEO	✓	✓		
ABS MONDEO 1.8L (DURATEC SCi)	✓	✓	✓	
ABS MONDEO 2.5L (DURATEC-VE 2.5L)	✓	✓		
ABS MONDEO 95	✓	✓		
ABS MONDEO 96 - 97	✓	✓		
ABS MONDEO 98	✓	✓		
ABS MOUNTAINEER/EXPLORER	✓	✓	✓	
ABS RANGER	✓	✓		
ABS TEVES MK20i (FIESTA / KA)	✓	✓		
ABS TRANSIT	✓	✓	✓	
ABS TRANSIT 2.0L/2.4L DURATORQ_DI	✓	✓	✓	
ABS TRANSIT 2.4L (CAN)	✓	✓		✓

<i>Special Functions</i>
<i>ABS Service Bleed</i>
<i>Calibrate the longitudinal acceleration sensor.</i>
<i>Configure the steering angle sensor.</i>
<i>Enable/Disable hill launch assist .</i>
<i>Learn the vehicle variant and VIN data.</i>
<i>Reset Pressure Sensor Offset</i>
<i>Variant and VIN Data Learning Procedure</i>

#### ARC - AUTOMATIC RIDE CONTROL

Sistema	DTC	Flujo de Datos	Actuadores	Config
ARC Generic	✓			

#### AUDIO CONTROL MODULE

Sistema	DTC	Flujo de Datos	Actuadores	Config
ACM - FIESTA MK VI	✓	✓		

<i>Special Functions</i>
<i>Programmable Module Installation</i>

Sistema	DTC	Flujo de Datos	Actuadores	Config
ACM - TRANSIT /TOURNEO CONNECT	✓	✓		✓

<i>Special Functions</i>
<i>ACM - Audio Control Module</i>

Sistema	DTC	Flujo de Datos	Actuadores	Config
ACM - TRANSIT MK VII	✓			
ACM FOCUS/FIESTA	✓	✓	✓	✓

<i>Special Functions</i>
<i>Programmable Module Installation</i>

Sistema	DTC	Flujo de Datos	Actuadores	Config
ACM MONDEO <2003	✓	✓		✓

<i>Special Functions</i>
<i>Programmable Module Installation</i>

Sistema	DTC	Flujo de Datos	Actuadores	Config
ACM MONDEO >2003	✓	✓		✓

<i>Special Functions</i>
<i>Programmable Module Installation</i>

**BCMii - BODY CONTROL MODULE**

Sistema	DTC	Flujo de Datos	Actuadores	Config
BCMii - FIESTA MK VI	✓	✓	⊘	👤
<i>Special Functions</i>				
Sistema	DTC	Flujo de Datos	Actuadores	Config
BCMii - GALAXY/SMAX/MONDEO MY08	✓	✓	⊘	✓
<i>Special Functions</i>				
<i>Ignition Key Erase</i>				
<i>Ignition Key Programming</i>				
<i>Module Initialization</i>				
<i>Sensor Learn Routine</i>				
Sistema	DTC	Flujo de Datos	Actuadores	Config
BCMii - TRANSIT MK VII	✓	✓	⊘	✓
<i>Special Functions</i>				
<i>Ignition Key Erase</i>				
<i>Ignition Key Programming</i>				
<i>Module Initialization</i>				

**CCMii - CRUISE CONTROL MODULE**

Sistema	DTC	Flujo de Datos	Actuadores	Config
CCMii - GALAXY/SMAX/MONDEO MY08	✓	✓	✓	⊘

**CDP - CD PLAYER**

Sistema	DTC	Flujo de Datos	Actuadores	Config
CDP FOCUS C-MAX	✓	✓	⊘	✓
<i>Special Functions</i>				
<i>Programmable Module Installation</i>				
Sistema	DTC	Flujo de Datos	Actuadores	Config
CDP MONDEO >2003	✓	✓	⊘	✓
<i>Special Functions</i>				
<i>Programmable Module Installation</i>				

**CMR - CAMERA MODULE REAR**

Sistema	DTC	Flujo de Datos	Actuadores	Config
CMR - MONDEO MY08	✓	✓	⊘	⊘

**CSM - CENTRAL SECURITY MODULE**

Sistema	DTC	Flujo de Datos	Actuadores	Config
CSM - FOCUS (ZETEC 2.0L/ZETEC-SE 1.6L)	✓	✓	✓	⊘
CSM - MONDEO (ZETEC 1.8L)	✓	⊘	✓	⊘
CSM - TRANSIT/TOURNEO CONNECT	✓	✓	✓	✓
<i>Special Functions</i>				
<i>Programmable Module Installation</i>				
Sistema	DTC	Flujo de Datos	Actuadores	Config
CSM FOCUS	✓	👤	👤	👤
CSM KA (DURATEC 8 V)	✓	✓	⊘	👤
CSM TRANSIT	✓	✓	✓	✓
<i>Special Functions</i>				
<i>Programmable Module Installation</i>				

**D\_DCU/DDM - DRIVER'S DOOR CONTROL UNIT**

Sistema	DTC	Flujo de Datos	Actuadores	Config
D_DCU FOCUS C-MAX	✓	✓	✓	✓

<i>Special Functions</i>				
<i>Module Reset</i>				
<i>Programmable Module Installation</i>				
<b>Sistema</b>	DTC	Flujo de Datos	Actuadores	Config
DDM - GALAXY/SMAX/MONDEO MY08	✓	✓	⊘	⊘
<b>DSM - DRIVER'S SEAT MODULE</b>				
<b>Sistema</b>	DTC	Flujo de Datos	Actuadores	Config
DSM - MONDEO MY08	✓	✓	✓	⊘
<b>EATC/HVAC - ELECTRONIC AUTOMATIC TEMPERATURE CONTROL MODULE</b>				
<b>Sistema</b>	DTC	Flujo de Datos	Actuadores	Config
EATC - FIESTA MY2006	✓	👤	✓	⊘
EATC FOCUS	✓	✓	✓	👤
EATC FOCUS C-MAX	✓	✓	✓	✓
<i>Special Functions</i>				
<i>Programmable Module Installation</i>				
<i>Replace Electronic Control Unit (ECU)</i>				
<b>Sistema</b>	DTC	Flujo de Datos	Actuadores	Config
EATC MONDEO <2003	✓	✓	✓	✓
<i>Special Functions</i>				
<i>Programmable Module Installation</i>				
<b>Sistema</b>	DTC	Flujo de Datos	Actuadores	Config
EATC MONDEO >2003	✓	✓	✓	✓
<i>Special Functions</i>				
<i>Programmable Module Installation</i>				
<b>Sistema</b>	DTC	Flujo de Datos	Actuadores	Config
EATC MOUNTAINEER/EXPLORER 4.6L 2V	✓	✓	✓	✓
<i>Special Functions</i>				
<i>Programmable Module Installation</i>				
<b>Sistema</b>	DTC	Flujo de Datos	Actuadores	Config
HVAC - FIESTA MK VI	✓	✓	⊘	👤
<i>Special Functions</i>				
<b>Sistema</b>	DTC	Flujo de Datos	Actuadores	Config
HVAC - GALAXY/SMAX/MONDEO MY08	✓	✓	⊘	⊘
<b>EPB/PBM - ELECTRIC PARKING BRAKE</b>				
<b>Sistema</b>	DTC	Flujo de Datos	Actuadores	Config
EPB FOCUS C-MAX	✓	✓	⊘	✓
<i>Special Functions</i>				
<i>Calibrate a new EPB module.</i>				
<i>Calibrate the emergency release.</i>				
<i>Calibrate the EPB function test.</i>				
<i>Programmable Module Installation</i>				
<b>Sistema</b>	DTC	Flujo de Datos	Actuadores	Config
PBM - GALAXY/SMAX/MONDEO MY08	✓	✓	⊘	⊘
<b>EPS/PSCM - ELECTRONIC CONTROLLED POWER STEERING</b>				
<b>Sistema</b>	DTC	Flujo de Datos	Actuadores	Config
ELECTRONIC CONTROLLED POWER STEERING (Fiesta-Diesel)	✓	✓	⊘	✓
<i>Special Functions</i>				
<i>Programmable Module Installation</i>				

Sistema	DTC	Flujo de Datos	Actuadores	Config
EPS FOCUS C-MAX	✓	✓	⊘	✓
<i>Special Functions</i>				
<i>Programmable Module Installation</i>				
Sistema	DTC	Flujo de Datos	Actuadores	Config
PSCM - FIESTA MK VI	✓	✓	⊘	👤
<i>Special Functions</i>				
Sistema	DTC	Flujo de Datos	Actuadores	Config
PSCM - GALAXY/SMAX/MONDEO MY08	✓	⊘	⊘	⊘
<b>FACM - FUEL ADDITIVE CONTROL MODULE</b>				
Sistema	DTC	Flujo de Datos	Actuadores	Config
FACM - FOCUS MKII	✓	✓	⊘	✓
<i>Special Functions</i>				
<i>Programmable Module Installation</i>				
<b>FCDIM - FRONT CONTROL/DISPLAY INTERFACE MODULE</b>				
Sistema	DTC	Flujo de Datos	Actuadores	Config
FCDIM - FIESTA MK VI	✓	✓	⊘	👤
<i>Special Functions</i>				
<b>FFH/AHCM - FUEL FIRED COOLANT HEATING MODULE</b>				
Sistema	DTC	Flujo de Datos	Actuadores	Config
AHCM - GALAXY/SMAX/MONDEO MY08	✓	✓	⊘	⊘
FFH - FOCUS 1.8L DURATORQ TDCI	✓	✓	✓	👤
FFH - MONDEO (ZETEC 1.8L)	✓	✓	⊘	⊘
FFH - TRANSIT MK VII	✓	✓	✓	⊘
FFH - TRANSIT/TOURNEO CONNECT	✓	✓	✓	⊘
FFH FOCUS C-MAX	✓	✓	✓	✓
<i>Special Functions</i>				
<i>FFH Unlock Utility</i>				
Sistema	DTC	Flujo de Datos	Actuadores	Config
FFH FOCUS C-MAX (DURATEC HE I4 1.8L/DURATEC 16V 1.6L)	✓	✓	✓	✓
<i>Special Functions</i>				
<i>FFH Unlock Utility</i>				
Sistema	DTC	Flujo de Datos	Actuadores	Config
FFH TRANSIT	✓	✓	✓	👤
<b>GDM - GENERIC DISPLAY MODULE</b>				
Sistema	DTC	Flujo de Datos	Actuadores	Config
GDM FOCUS C-MAX	✓	✓	⊘	✓
<i>Special Functions</i>				
<i>Disable GDM VIN</i>				
<i>Programmable Module Installation</i>				
Sistema	DTC	Flujo de Datos	Actuadores	Config
GDM MONDEO >2003	✓	✓	⊘	✓
<i>Special Functions</i>				
<i>Programmable Module Installation</i>				
<b>GEM - GENERIC ELECTRONIC MODULE</b>				
Sistema	DTC	Flujo de Datos	Actuadores	Config
CTM FOCUS 1999 MY	✓	✓	⊘	👤
GEM - FIESTA (DURATEC 16V)	✓	✓	✓	✓

<i>Special Functions</i>				
<i>Programmable Module Installation</i>				
<b>Sistema</b>	DTC	Flujo de Datos	Actuadores	Config
GEM - I4 DSL ELECTRONIC 3.0L (RANGER)	✓	✓	✓	✓
<i>Special Functions</i>				
<i>Programmable Module Installation</i>				
<b>Sistema</b>	DTC	Flujo de Datos	Actuadores	Config
GEM - PUMA	✓	✓	✓	👤
GEM (FIESTA 1.4L) (DURATEC 16V)	✓	✓	✓	✓
<i>Special Functions</i>				
<i>Programmable Module Installation</i>				
<b>Sistema</b>	DTC	Flujo de Datos	Actuadores	Config
GEM (F-SERIES 3.9L Cummins Diesel)	✓	✓	✓	👤
GEM (F-SERIES SUPER DUTY DIRECT INJECTION - TURBO 7.3L)	✓	✓	✓	🚫
GEM (KA 1.3 DURATEC 8V)	✓	✓	✓	✓
<i>Special Functions</i>				
<i>Programmable Module Installation</i>				
<b>Sistema</b>	DTC	Flujo de Datos	Actuadores	Config
GEM (KA STREET 1.6L DURATEC 8V)	✓	✓	✓	✓
<i>Special Functions</i>				
<i>Programmable Module Installation</i>				
<b>Sistema</b>	DTC	Flujo de Datos	Actuadores	Config
GEM FIESTA- FUSION - MONDEO	✓	✓	✓	👤
GEM FOCUS	✓	✓	✓	✓
<i>Special Functions</i>				
<i>Programmable Module Installation</i>				
<b>Sistema</b>	DTC	Flujo de Datos	Actuadores	Config
GEM FOCUS C-MAX	✓	✓	✓	✓
<i>Special Functions</i>				
<i>Module Reset</i>				
<i>Programmable Module Installation</i>				
<b>Sistema</b>	DTC	Flujo de Datos	Actuadores	Config
GEM MONDEO (DURATEC Sci 1.8L ) <2003	✓	✓	✓	✓
<i>Special Functions</i>				
<i>Programmable Module Installation</i>				
<b>Sistema</b>	DTC	Flujo de Datos	Actuadores	Config
GEM MONDEO DURATORQ DI 2.0L	✓	✓	✓	✓
<i>Special Functions</i>				
<i>Programmable Module Installation</i>				
<b>Sistema</b>	DTC	Flujo de Datos	Actuadores	Config
GEM RANGER	✓	✓	👤	👤
<b>HCM - HEADLIGHT CONTROL MODULE</b>				
<b>Sistema</b>	DTC	Flujo de Datos	Actuadores	Config
HCM - GALAXY/SMAX/MONDEO MY08	✓	✓	🚫	✓
<i>Special Functions</i>				
<i>Headlamp Alignment</i>				
<b>Sistema</b>	DTC	Flujo de Datos	Actuadores	Config
HCM - HEADLIGHT CONTROL MODULE	✓	✓	🚫	✓

<i>Special Functions</i>				
<i>Programmable Module Installation</i>				
<b>Sistema</b>	DTC	Flujo de Datos	Actuadores	Config
HCM FOCUS	✓	✓	🚫	👤
HCM FOCUS (I5 2.5L)	✓	✓	🚫	✓
<i>Special Functions</i>				
<i>Programmable Module Installation</i>				
<b>Sistema</b>	DTC	Flujo de Datos	Actuadores	Config
HCM FOCUS C-MAX (DURATEC HE I4 1.8L)	✓	✓	🚫	✓
<i>Special Functions</i>				
<i>Programmable Module Installation</i>				
<b>HEC - HYBRID ELECTRONIC CLUSTER</b>				
<b>Sistema</b>	DTC	Flujo de Datos	Actuadores	Config
HEC - TRANSIT /TOURNEO CONNECT	✓	✓	✓	✓
<i>Special Functions</i>				
<i>Programmable Module Installation</i>				
<b>Sistema</b>	DTC	Flujo de Datos	Actuadores	Config
HEC (F-SERIES 3.9L Cummins Diesel)	✓	✓	✓	✓
<i>Special Functions</i>				
<i>Customer Spare Key Programming Disable</i>				
<i>Customer Spare Key Programming Enable</i>				
<i>Erased and Key Programming</i>				
<i>IC Parameter Reset</i>				
<i>Ignition Key Erase</i>				
<i>Ignition Key Programming</i>				
<i>PCM Parameter Reset</i>				
<b>Sistema</b>	DTC	Flujo de Datos	Actuadores	Config
HEC FOCUS	✓	✓	✓	✓
<i>Special Functions</i>				
<i>Programmable Module Installation</i>				
<b>Sistema</b>	DTC	Flujo de Datos	Actuadores	Config
HEC FOCUS 1999 MY	✓	👤	👤	✓
<i>Special Functions</i>				
<i>Programmable Module Installation</i>				
<b>Sistema</b>	DTC	Flujo de Datos	Actuadores	Config
HEC MONDEO	✓	✓	✓	✓
<i>Special Functions</i>				
<i>Programmable Module Installation</i>				
<b>Sistema</b>	DTC	Flujo de Datos	Actuadores	Config
HEC MONDEO (DURATEC SCi 1.8L)	✓	✓	✓	✓
<i>Special Functions</i>				
<i>Programmable Module Installation</i>				
<b>Sistema</b>	DTC	Flujo de Datos	Actuadores	Config
HEC TRANSIT	✓	✓	✓	✓
<i>Special Functions</i>				
<i>Odometer Write</i>				
<i>Programmable Module Installation</i>				
<b>IABM/RCM - INTEGRATED AIRBAG MONITOR</b>				

Sistema	DTC	Flujo de Datos	Actuadores	Config
AIRBAG (ECS) FOCUS MY 1999	✓	✓	⊘	✓
<i>Special Functions</i>				
<i>Market</i>				
<i>PROGRAM</i>				
<i>Right Hand Drive</i>				
<i>Side Airbags</i>				
Sistema	DTC	Flujo de Datos	Actuadores	Config
AIRBAG (F-SERIES 3.9L Cummins Diesel)	✓	✓	✓	👤
AIRBAG ECO-SPORT (RCM)	✓	✓	⊘	⊘
AIRBAG FIESTA (RCM)	✓	✓	⊘	⊘
AIRBAG FOCUS C-MAX (RCM)	✓	⊘	⊘	✓
<i>Special Functions</i>				
<i>Passenger Airbag Deactivation</i>				
<i>Programmable Module Installation</i>				
Sistema	DTC	Flujo de Datos	Actuadores	Config
AIRBAG FRONT RCM ( TRANSIT / RANGER)	✓	✓	👤	👤
AIRBAG FUSION-FIESTA (RCM)	✓	✓	⊘	✓
<i>Special Functions</i>				
<i>Programmable Module Installation</i>				
Sistema	DTC	Flujo de Datos	Actuadores	Config
AIRBAG MAZDA	✓	✓	⊘	👤
AIRBAG MONDEO (DURATEC SCi 1.8L)	✓	✓	⊘	👤
AIRBAG MONDEO (RCM)	✓	✓	⊘	👤
AIRBAG MOUNTAINEER (RCM)	✓	✓	✓	⊘
ECS - TRANSIT/TOURNEO CONNECT	✓	✓	⊘	✓
<i>Special Functions</i>				
<i>Programmable Module Installation</i>				
Sistema	DTC	Flujo de Datos	Actuadores	Config
ECS (KA 1.3L) (DURATEC 8V)	✓	✓	⊘	✓
<i>Special Functions</i>				
<i>Programmable Module Installation</i>				
Sistema	DTC	Flujo de Datos	Actuadores	Config
ECS (Street Ka 1,6L) (DURATEC 8V)	✓	⊘	⊘	✓
<i>Special Functions</i>				
<i>Programmable Module Installation</i>				
Sistema	DTC	Flujo de Datos	Actuadores	Config
IABM Generic	✓	👤	👤	👤
RCM - FIESTA MK VI	✓	✓	⊘	⊘
RCM - FOCUS 1.8L (DURATORQ TDCI / ZETEC)	✓	✓	✓	✓
<i>Special Functions</i>				
<i>Programmable Module Installation</i>				
Sistema	DTC	Flujo de Datos	Actuadores	Config
RCM - F-SERIES SUPER DUTY	✓	✓	✓	⊘
RCM - GALAXY/SMAX/MONDEO MY08	✓	✓	⊘	⊘
RCM - I4 DSL ELECTRONIC 3.0L (RANGER)	✓	✓	⊘	👤
RCM - TRANSIT MK VII	✓	✓	⊘	⊘
RCM TRANSIT	✓	✓	⊘	👤

Sistema	DTC	Flujo de Datos	Actuadores	Config
IC - FOCUS I5 2.5L	✓	✓	✓	✓
<i>Special Functions</i>				
<i>Programmable Module Installation</i>				
Sistema	DTC	Flujo de Datos	Actuadores	Config
IC - I4 DSL ELECTRONIC 3.0L - RANGER	✓	✓	✓	✓
<i>Special Functions</i>				
<i>Programmable Module Installation</i>				
Sistema	DTC	Flujo de Datos	Actuadores	Config
IC - TRANSIT (DURATORQ 1.8L TDCR)	✓	✓	✓	👤
IC FOCUS (DURATEC 16V)	✓	✓	✓	✓
<i>Special Functions</i>				
<i>Programmable Module Installation</i>				
Sistema	DTC	Flujo de Datos	Actuadores	Config
IC FOCUS C-MAX	✓	✓	✓	✓
<i>Special Functions</i>				
NAV - NAVIGATION SYSTEM				
<i>Programmable Module Installation</i>				
Wash / Wipe				
Sistema	DTC	Flujo de Datos	Actuadores	Config
IC MAZDA	✓	✓	🚫	👤
IC MOUNTAINEER/EXPLORER	✓	✓	✓	✓
<i>Special Functions</i>				
<i>Programmable Module Installation</i>				
Sistema	DTC	Flujo de Datos	Actuadores	Config
INSTRUMENT PANEL (Fiesta)	✓	✓	✓	✓
<i>Special Functions</i>				
<i>Programmable Module Installation</i>				
Sistema	DTC	Flujo de Datos	Actuadores	Config
INSTRUMENT PANEL (Focus)	✓	✓	✓	👤
INSTRUMENT PANEL (Fusion-Fiesta)	✓	✓	✓	✓
<i>Special Functions</i>				
Odometer Write				
<i>Programmable Module Installation</i>				
Sistema	DTC	Flujo de Datos	Actuadores	Config
INSTRUMENTS PANEL (Eco Sport)	✓	✓	✓	✓
<i>Special Functions</i>				
<i>Programmable Module Installation</i>				
Sistema	DTC	Flujo de Datos	Actuadores	Config
IPC - FIESTA MK VI	✓	✓	✓	🚫
IPC - GALAXY/SMAX/MONDEO MY08	✓	✓	🚫	🚫
IPC - TRANSIT MK VII	✓	✓	🚫	🚫
LHID - LEFT HIGH INTENSITY DISCHARGE LAMP				
Sistema	DTC	Flujo de Datos	Actuadores	Config
LHID MONDEO (DURATEC SCI 1.8L)	✓	✓	✓	✓
<i>Special Functions</i>				
MCM - MESSAGE CENTER MODULE				

Sistema	DTC	Flujo de Datos	Actuadores	Config
MC - FOCUS I5 2.5L	✓	✓	✓	✓
<i>Special Functions</i>				
<i>Programmable Module Installation</i>				
Sistema	DTC	Flujo de Datos	Actuadores	Config
MCM FOCUS	✓	✓	✓	✓
<i>Special Functions</i>				
<i>Programmable Module Installation</i>				
NAV - NAVIGATION SYSTEM				
Sistema	DTC	Flujo de Datos	Actuadores	Config
NAV FOCUS C-MAX	✓	✓	⊘	👤
NAV MONDEO >2003	✓	✓	⊘	👤
NETWORK INFORMATION				
Sistema	DTC	Flujo de Datos	Actuadores	Config
NETWORK ANALYSIS (CAN)	👤	⊘	⊘	✓
<i>Special Functions</i>				
<i>Get network information</i>				
Sistema	DTC	Flujo de Datos	Actuadores	Config
NETWORK ANALYSIS (J1850)	👤	⊘	⊘	✓
<i>Special Functions</i>				
<i>Get network information</i>				
OTC - OVERHEAD TRIP COMPUTER				
Sistema	DTC	Flujo de Datos	Actuadores	Config
OTC (F-SERIES SUPER DUTY)	✓	✓	⊘	✓
<i>Special Functions</i>				
<i>Programmable Module Installation</i>				
PAM - PARKING AID COMPUTER				
Sistema	DTC	Flujo de Datos	Actuadores	Config
PAM - GALAXY/SMAX/MONDEO MY08	✓	✓	⊘	⊘
PAM - MOUNTAINEER/TRANSIT/TOURNEO CONNECT	✓	✓	✓	⊘
PAM - TRANSIT MK VII	✓	✓	⊘	⊘
PAM FOCUS C-MAX	✓	✓	⊘	✓
<i>Special Functions</i>				
<i>Programmable Module Installation</i>				
Sistema	DTC	Flujo de Datos	Actuadores	Config
PAM TRANSIT	✓	✓	⊘	⊘
PAM TRANSIT 2.0L/2.4L DURATORQ_DI	✓	👤	✓	👤
PATS - PASSIVE ANTI THEFT MODULE				
Sistema	DTC	Flujo de Datos	Actuadores	Config
PATS - FOCUS 1.6L ZETEC-SE	✓	✓	⊘	⊘
PATS (CAN)	👤	⊘	⊘	⊘
PATS (J1850)	👤	⊘	⊘	⊘
PATS I (ISO)	✓	✓	⊘	✓
<i>Special Functions</i>				
<i>Ignition Key Erase</i>				
<i>Remote control learning</i>				
Sistema	DTC	Flujo de Datos	Actuadores	Config
PATS I (PWM)	✓	✓	⊘	⊘
PATS II	✓	✓	⊘	✓

<i>Special Functions</i>
<i>Coded</i>
<i>Fleet or Hire Vehicle Mode</i>
<i>Ignition Key Erase</i>
<i>Key Programming</i>
<i>Module Initialization</i>
<i>Read</i>
<i>Temporized</i>

Sistema	DTC	Flujo de Datos	Actuadores	Config
PATS II ( FOCUS DURATEC 2.0 - CAN )	✓	✓	⊘	✓

<i>Special Functions</i>
<i>Coded</i>
<i>Customer Spare Key Programming Disable</i>
<i>Customer Spare Key Programming Enable</i>
<i>Ignition Key Code Erase</i>
<i>PATS Functions</i>
<i>Program additional ignition key.</i>
<i>Temporized</i>

Sistema	DTC	Flujo de Datos	Actuadores	Config
PATS II (CAN)	✓	✓	⊘	✓

<i>Special Functions</i>
<i>Coded</i>
<i>Erased and Key Programming (Timed)</i>
<i>Fleet or Hire Vehicle Mode</i>
<i>Ignition Key Erase</i>
<i>Ignition Key Programming</i>
<i>Module Initialization</i>
<i>Read</i>
<i>Temporized</i>

Sistema	DTC	Flujo de Datos	Actuadores	Config
PATS II CODED_06	✓	⊘	⊘	✓

<i>Special Functions</i>
<i>Coded</i>
<i>Ignition Key Erase</i>
<i>Ignition Key Programming</i>
<i>Module Initialization</i>

**PCM - POWERTRAIN CONTROL MODULE**

Sistema	DTC	Flujo de Datos	Actuadores	Config
2V 4.6L PETROL (MOUNTAINEER/EXPLORER)	✓	✓	⊘	✓

<i>Special Functions</i>
<i>Passenger Seat Weight Sensor ReZero</i>
<i>Personality</i>
<i>Ride Height Calibration</i>
<i>Warning Lamps / Chimes</i>

Sistema	DTC	Flujo de Datos	Actuadores	Config
DIESEL Generico	✓	✓	✓	👤
DIRECT INJECTION - TURBO 7.3L	✓	✓	⊘	⊘
DURATEC 16V (FIESTA)	✓	✓	✓	✓

<i>Special Functions</i>
<i>Power Door Locks</i>

Sistema	DTC	Flujo de Datos	Actuadores	Config
DURATEC 16V (FOCUS)	✓	✓	✓	✓

<i>Special Functions</i>
<i>IVD Initialization Sequence</i>
<i>Power Door Locks</i>
<i>Security</i>
<i>Warning Lamps / Chimes</i>
<i>Washer / Wiper</i>

Sistema	DTC	Flujo de Datos	Actuadores	Config
DURATEC 16V 1.6L (FOCUS / C-MAX)	✓	✓	⊘	✓

<i>Special Functions</i>
<i>ABS Service Bleed</i>
<i>Audio Configure</i>
<i>Auto Lock</i>
<i>Auxiliary vehicle ID reset</i>
<i>Calibrate the emergency release.</i>
<i>Calibrate the EPB function test.</i>
<i>Configure All Three Sensors Together.</i>
<i>Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.</i>
<i>Configure the pressure sensor.</i>
<i>Disable GDM VIN</i>
<i>EAH Further Information</i>
<i>FFH SelfTest and Prefill Utility</i>
<i>FFH Start Heater Utility</i>
<i>FFH Unlock Utility</i>
<i>FFPH Conditions For Start-up</i>
<i>FFPH Further Information</i>
<i>FFPH Heater Operation</i>
<i>Module Reset</i>
<i>Navigation system</i>
<i>Odometer Write</i>
<i>Passenger Airbag Deactivation</i>
<i>Security</i>
<i>Show GEM configuration</i>
<i>Warning Lamps / Chimes</i>
<i>Washer / Wiper</i>

Sistema	DTC	Flujo de Datos	Actuadores	Config
DURATEC 8V (KA - STREET KA)	✓	✓	⊘	✓

<i>Special Functions</i>
<i>Washer / Wiper</i>

Sistema	DTC	Flujo de Datos	Actuadores	Config
DURATEC SCi 1.8L (MONDEO)	✓	✓	⊘	✓

<i>Special Functions</i>
<i>Audio Configure</i>
<i>Personality</i>
<i>Power Door Locks</i>
<i>Power Window</i>
<i>Security</i>
<i>Warning Lamps / Chimes</i>
<i>Washer / Wiper</i>

Sistema	DTC	Flujo de Datos	Actuadores	Config
DURATEC VCT	✓	✓	⊘	✓

<i>Special Functions</i>
<i>Audio Configure</i>
<i>NAV - NAVIGATION SYSTEM</i>

Passenger Airbag Deactivation
Personality
Power Door Locks
Security
Speed Items
Warning Lamps / Chimes
Wash / Wipe

Sistema	DTC	Flujo de Datos	Actuadores	Config
DURATEC-HE / I4 1.8L (FOCUS C-MAX)	✓	✓	✓	✓

<b>Special Functions</b>
Audio Configure
NAV - NAVIGATION SYSTEM
Passenger Airbag Deactivation
Personality
Power Door Locks
Security
Speed Items
Warning Lamps / Chimes
Wash / Wipe

Sistema	DTC	Flujo de Datos	Actuadores	Config
DURATEC-HE / I4 2.0L	✓	✓	⊘	✓

<b>Special Functions</b>
Warning Lamps / Chimes

Sistema	DTC	Flujo de Datos	Actuadores	Config
DURATEC-HE / I4 2.3L	✓	✓	⊘	✓

<b>Special Functions</b>
Configure the lateral acceleration sensor.
Configure the longitudinal acceleration sensor.
Configure the steering angle sensor.
Configure the yaw rate sensor.
Headlamp Alignment
Parameter reset/configuration
Pressure Sensor Calibration
Read the ECU serial number.
Read the sensor cluster serial number.

Sistema	DTC	Flujo de Datos	Actuadores	Config
DURATEC-HE / I4 2.3L (Transit MK VII)	✓	✓	✓	✓

<b>Special Functions</b>
ABS - Antilock braking system
ABS Service Bleed
ACM - Audio Control Module
Calibrate the longitudinal acceleration sensor.
Configure the steering angle sensor.
Enable/Disable hill launch assist .
Learn the vehicle variant and VIN data.
Odometer Write
PAD Switch
RCM - Restraint Control Module
Reset KAM (Keep Alive Memory)
Reset Pressure Sensor Offset
Variant and VIN Data Learning Procedure

Sistema	DTC	Flujo de Datos	Actuadores	Config
DURATORQ - TDCRI (TRANSIT 1.8L)	✓	✓	✓	✓

<b>Special Functions</b>				
Audio Configure				
Odometer Write				
Reset Differential Pressure Sensor Learned Values				
Reset KAM (Keep Alive Memory)				
Reset the Diesel Particulate Filter Learned Values				
Reset the Exhaust Gas Recirculation Valve Learned Values				
Reset the Fuel Metering Valve Learned Values				
Reset the Knock Sensor Learned Values				
Reset the water in fuel Warning Indicator.				
<b>Sistema</b>				
DURATORQ TDCI (FOCUS 1.8L)	✓	✓	✓	✓
<b>Special Functions</b>				
Fuel Injector Correction Factors				
IVD Initialization Sequence				
Power Door Locks				
Security				
Warning Lamps / Chimes				
Washer / Wiper				
<b>Sistema</b>				
DURATORQ TDCI (MONDEO 2.0L)	✓	✓	✓	✓
<b>Special Functions</b>				
Injector programming				
<b>Sistema</b>				
DURATORQ TDCI (TRANSIT 2.0-2.4L)	✓	✓	⊘	✓
<b>Special Functions</b>				
Engine Oil Quality History				
Fuel Injection Pump Learn				
IABM/RCM - INTEGRATED AIRBAG MONITOR				
Odometer Write				
PAD Switch				
Restablezca el valor de temperatura de los gases de escape				
Speed Limiting				
<b>Sistema</b>				
DURATORQ TDCI (TRANSIT 2.0L)	✓	✓	✓	✓
<b>Special Functions</b>				
ABS Service Bleed				
Depressurize ASM system				
Fuel Injector Correction Factors				
Learn Clutch Parameter				
Learn Clutch Touch Point				
Learn Transmission				
Odometer Write				
Shift Actuator Bleed				
Warning Lamps / Chimes				
<b>Sistema</b>				
DURATORQ TDCRI 1.4L (FIESTA MK V)	👤	✓	✓	✓
<b>Special Functions</b>				
Auto Lock				
IVD Initialization Sequence				
<b>Sistema</b>				
DURATORQ TDCRI 1.6L (FIESTA)	✓	✓	✓	✓

<i>Special Functions</i>
<i>Personality</i>
<i>Power Door Locks</i>

Sistema	DTC	Flujo de Datos	Actuadores	Config
DURATORQ TURBO DIESEL COMMON RAIL INJECTION 1.6/1.8/2.0L FOCUS C-MAX	✓	✓	✓	✓

<i>Special Functions</i>
<i>Adaptive Front Lighting System</i>
<i>Audio Configure</i>
<i>Configure All Three Sensors Together.</i>
<i>Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.</i>
<i>Configure the pressure sensor.</i>
<i>Diesel Particulate Filter Static Regeneration</i>
<i>EAH Further Information</i>
<i>FFH SelfTest and Prefill Utility</i>
<i>FFH Start Heater Utility</i>
<i>FFH Unlock Utility</i>
<i>FFPH Conditions For Start-up</i>
<i>FFPH Further Information</i>
<i>FFPH Heater Operation</i>
<i>Fuel Injector Correction Factors</i>
<i>HID headlamps</i>
<i>New FACM (Fuel Additive Control Module)</i>
<i>Personality</i>
<i>Power Door Locks</i>
<i>Refill the FAT (Fuel Additive Tank)</i>
<i>Reset the Diesel Particulate Filter Learned Values</i>
<i>Reset the Exhaust Gas Recirculation Valve Learned Values</i>
<i>Security</i>
<i>Show GEM configuration</i>
<i>Speed Items</i>
<i>System Prime</i>
<i>Warning Lamps / Chimes</i>

Sistema	DTC	Flujo de Datos	Actuadores	Config
DURATORQ-DI	✓	✓	⊘	✓

<i>Special Functions</i>
<i>Audio Configure</i>
<i>Personality</i>
<i>Power Door Locks</i>
<i>Power Window</i>
<i>Security</i>
<i>Warning Lamps / Chimes</i>
<i>Washer / Wiper</i>

Sistema	DTC	Flujo de Datos	Actuadores	Config
DURATORQ-DI 2.0-2.4L (TRANSIT)	✓	✓	✓	✓

<i>Special Functions</i>
<i>ABS Service Bleed</i>
<i>Depressurize ASM system</i>
<i>Learn Clutch Parameter</i>
<i>Learn Clutch Touch Point</i>
<i>Learn Transmission</i>
<i>Shift Actuator Bleed</i>

Sistema	DTC	Flujo de Datos	Actuadores	Config
DURATORQ-TURBO DIESEL COMMON RAIL INJECTION 2.0L (MONDEO MY 2008)	✓	✓	⊘	✓

<b>Special Functions</b>
Assembly Check
CCMii Sensor Alignment
Configure the lateral acceleration sensor.
Configure the longitudinal acceleration sensor.
Configure the steering angle sensor.
Configure the yaw rate sensor.
Diesel Particulate Filter Static Regeneration
Fuel Injector Correction Factors
Headlamp Alignment
Odometer Write
Pressure Sensor Calibration
RCM - Restraint Control Module
Read the sensor cluster serial number.
Reset Differential Pressure Sensor Learned Values
Reset KAM (Keep Alive Memory)
Reset the Diesel Particulate Filter Learned Values
Reset the Exhaust Gas Recirculation Valve Learned Values
Reset the Fuel Metering Valve Learned Values
Reset the Intake Air Throttle Valve Learned Values
Reset the Knock Sensor Learned Values
Reset the water in fuel Warning Indicator.
Sensor Learn Routine
Workshop test

Sistema	DTC	Flujo de Datos	Actuadores	Config
EEC IV Zetec	✓	✓	⊘	⊘
EEC V (GENERIC - ALL ENGINES)	✓	✓	✓	⊘
ENDURA DI 1.8L (TRANSIT)	✓	✓	⊘	✓

<b>Special Functions</b>
CSM - Security module
ECS - Electronic Crash Sensor
HEC - Hybrid Electronic Cluster
Odometer Write
Warning Lamps / Chimes

Sistema	DTC	Flujo de Datos	Actuadores	Config
I4 DSL ELECTRONIC 3.0L (RANGER)	✓	✓	✓	✓

<b>Special Functions</b>
Airbag
Driveline
Personality
Security
Tire Size
Warning Lamps / Chimes

Sistema	DTC	Flujo de Datos	Actuadores	Config
I5 / 2.5L (FOCUS)	✓	✓	✓	✓

<b>Special Functions</b>
Audio Configure
NAV - NAVIGATION SYSTEM
Passenger Airbag Deactivation
Personality
Power Door Locks
Security
Warning Lamps / Chimes
Wash / Wipe

Sistema	DTC	Flujo de Datos	Actuadores	Config
I5 2.5L (MONDEO MKIV)	✓	✓	⊘	✓
<b>Special Functions</b>				
Assembly Check				
CCMii Sensor Alignment				
Clear stored clutch engagement point				
Headlamp Alignment				
Inclination Sensor Calibration				
Maintenance mode				
Odometer Write				
RCM - Restraint Control Module				
Sensor Learn Routine				
Static Apply				
Workshop test				
Sistema	DTC	Flujo de Datos	Actuadores	Config
ICU - DURATORQ TDCI 2.0L (TRANSIT)	👤	✓	⊘	👤
MAZDA2 (EURO STG3/4 Specs.) (MZI 1.4L)	✓	✓	✓	👤
PCM - DURATEC 16V 1.25L (FIESTA MK VI)	✓	✓	⊘	✓
<b>Special Functions</b>				
PATS information				
System Status				
Sistema	DTC	Flujo de Datos	Actuadores	Config
PCM - DURATEC-HE / I4 2.0L (FOCUS C-MAX)	✓	✓	✓	✓
<b>Special Functions</b>				
Auxiliary vehicle ID reset				
Disable GDM VIN				
FFH SelfTest and Prefill Utility				
FFH Start Heater Utility				
FFH Unlock Utility				
FFPH Conditions For Start-up				
FFPH Further Information				
FFPH Heater Operation				
Reset KAM (Keep Alive Memory)				
Sistema	DTC	Flujo de Datos	Actuadores	Config
PCM - DURATEC-VE 2.5L	✓	✓	⊘	👤
<b>Special Functions</b>				
Sistema	DTC	Flujo de Datos	Actuadores	Config
PCM - DURATORQ TDCRI 1.4L (MERCOSUR)	✓	✓	⊘	✓
<b>Special Functions</b>				
Warning Lamps / Chimes				
Warning Lamps / Chimes (FIESTA 1.4L DURATORQ TDCI)				
Sistema	DTC	Flujo de Datos	Actuadores	Config
PCM - DURATORQ TURBO DIESEL COMMON RAIL INJECTION (TDCI) 1.8L (GALAXY/SMAX)	✓	✓	⊘	✓
<b>Special Functions</b>				
Configure the lateral acceleration sensor.				
Configure the longitudinal acceleration sensor.				
Configure the steering angle sensor.				
Configure the yaw rate sensor.				
EPB/PBM - ELECTRIC PARKING BRAKE				
Headlamp Alignment				
IABM/RCM - INTEGRATED AIRBAG MONITOR				
Pressure Sensor Calibration				

Read the ECU serial number.

Read the sensor cluster serial number.

Sensor Learn Routine

Sistema	DTC	Flujo de Datos	Actuadores	Config
PCM - ENDURA-E 1.3L (KA)	✓	✓	⊘	👤

Special Functions

Sistema	DTC	Flujo de Datos	Actuadores	Config
PCM - ZETEC 1.8L (FOCUS)	✓	✓	⊘	✓

Special Functions

Auto Lock

IVD Initialization Sequence

Security

Warning Lamps / Chimes

Washer / Wiper

Sistema	DTC	Flujo de Datos	Actuadores	Config
PCM - ZETEC 1.8L (TRANSIT)	✓	✓	⊘	✓

Special Functions

Odometer Write

Warning Lamps / Chimes

Sistema	DTC	Flujo de Datos	Actuadores	Config
PCM - ZETEC 2.0L (FOCUS)	✓	✓	⊘	👤

Special Functions

Sistema	DTC	Flujo de Datos	Actuadores	Config
PCM - ZETEC ROCAM 1.6L	✓	✓	⊘	✓

Special Functions

Programmable Module Installation

Reset KAM (Keep Alive Memory)

Tire Size / Axle Ratio

Warning Lamps / Chimes (ECOSPORT 1.6L (ZETEC ROCAM))

Warning Lamps / Chimes (FIESTA 1.4L ZETEC ROCAM)

Sistema	DTC	Flujo de Datos	Actuadores	Config
ZETEC 1.6L	✓	✓	⊘	✓

Special Functions

Sistema	DTC	Flujo de Datos	Actuadores	Config
ZETEC 1.8L (MONDEO)	✓	✓	⊘	👤

ZETEC 2.0L	✓	✓	✓	👤
------------	---	---	---	---

Special Functions

Sistema	DTC	Flujo de Datos	Actuadores	Config
ZETEC 2.0L (MONDEO)	✓	✓	✓	👤

Special Functions

Sistema	DTC	Flujo de Datos	Actuadores	Config
ZETEC ROCAM 1.0L (KA)	✓	✓	✓	👤

Special Functions

Sistema	DTC	Flujo de Datos	Actuadores	Config
ZETEC ROCAM 1.6L (KA)	✓	✓	⊘	👤

Special Functions

Sistema	DTC	Flujo de Datos	Actuadores	Config
ZETEC-SE 1.6L (FOCUS)	✓	✓	⊘	✓

<i>Special Functions</i>				
CTM - Central timer module				
ECS - Electronic Crash Sensor				
HEC - Hybrid Electronic Cluster				
<b>Sistema</b>	DTC	Flujo de Datos	Actuadores	Config
ZETEC-SE 1.7L (PUMA)	✓	✓	⊘	✓
<i>Special Functions</i>				
Auto Lock				
GEM - GENERIC ELECTRONIC MODULE				
<b>PDM - PASSENGER'S DOOR MODULE</b>				
<b>Sistema</b>	DTC	Flujo de Datos	Actuadores	Config
PDM - GALAXY/SMAX/MONDEO MY08	✓	✓	⊘	⊘
PDM FOCUS C-MAX	✓	✓	✓	👤
<b>RAP - REMOTE ANTI THEFT MODULE</b>				
<b>Sistema</b>	DTC	Flujo de Datos	Actuadores	Config
RAP RANGER	✓	👤	👤	👤
<b>RASM - REAR AIR SUSPENSION MODULE</b>				
<b>Sistema</b>	DTC	Flujo de Datos	Actuadores	Config
RASM TRANSIT 2.0L/2.4L DURATORO_DI	✓	✓	✓	👤
<b>RETM - REAR ENTERTAINMENT MODULE</b>				
<b>Sistema</b>	DTC	Flujo de Datos	Actuadores	Config
RETM FOCUS C-MAX	✓	✓	⊘	✓
<i>Special Functions</i>				
Programmable Module Installation				
<b>Sistema</b>	DTC	Flujo de Datos	Actuadores	Config
RETM MONDEO >2003	✓	✓	⊘	👤
<b>RFA - REMOTE FUNCTION ACTUATOR</b>				
<b>Sistema</b>	DTC	Flujo de Datos	Actuadores	Config
RFA - FIESTA MK VI	✓	✓	⊘	⊘
RFA - GALAXY/SMAX/MONDEO MY08	✓	✓	⊘	⊘
<b>RGTM - REAR GATE/TRUNK MODULE</b>				
<b>Sistema</b>	DTC	Flujo de Datos	Actuadores	Config
RGTM - GALAXY/SMAX	✓	⊘	⊘	⊘
<b>RHID - RIGHT HIGH INTENSITY DISCHARGE LAMP</b>				
<b>Sistema</b>	DTC	Flujo de Datos	Actuadores	Config
RHID MONDEO (DURATEC SCI 1.8L)	✓	✓	⊘	👤
<b>RHVAC - REMOTE HEATING VENTILATION AIR CONDITIONING</b>				
<b>Sistema</b>	DTC	Flujo de Datos	Actuadores	Config
RHVAC - GALAXY/SMAX	✓	✓	⊘	⊘
<b>RIM - REMOTE IMMOBILIZER MODULE</b>				
<b>Sistema</b>	DTC	Flujo de Datos	Actuadores	Config
RIM Generic	✓	👤	👤	👤
<b>RKE - REMOTE KEYLESS ENTRY</b>				
<b>Sistema</b>	DTC	Flujo de Datos	Actuadores	Config
REMOTE KEYLESS ENTRY (FIESTA-ECOSPORT)	✓	✓	✓	⊘
RKE FOCUS C-MAX	✓	✓	⊘	✓
<i>Special Functions</i>				

<i>Install a new module in vehicle</i>				
<i>Module Initialization</i>				
<i>Programmable Module Installation</i>				
<i>System status</i>				
<b>RL_DCU - REAR LEFT DOOR CONTROL UNIT</b>				
Sistema	DTC	Flujo de Datos	Actuadores	Config
RL_DCU FOCUS C-MAX	✓	✓	✓	✓
<i>Special Functions</i>				
<i>Module Reset</i>				
<b>RR_DCU - REAR RIGHT DOOR CONTROL UNIT</b>				
Sistema	DTC	Flujo de Datos	Actuadores	Config
RR_DCU FOCUS C-MAX	✓	✓	✓	✓
<i>Special Functions</i>				
<i>Module Reset</i>				
<b>SASM - STEERING ANGLE SENSOR MODULE</b>				
Sistema	DTC	Flujo de Datos	Actuadores	Config
SASM - GALAXY/SMAX/MONDEO MY08	✓	✓	⊘	⊘
<b>SRM - SPEECH RECOGNITION MODULE</b>				
Sistema	DTC	Flujo de Datos	Actuadores	Config
SRM - FIESTA MK VI	✓	✓	⊘	👤
<i>Special Functions</i>				
<i>Programmable Module Installation</i>				
Sistema	DTC	Flujo de Datos	Actuadores	Config
SRM - GALAXY/SMAX/MONDEO MY08	✓	✓	⊘	⊘
SRM - TRANSIT MK VII	✓	⊘	⊘	⊘
SRM FOCUS/FIESTA	✓	✓	⊘	👤
SRM MONDEO >2003	✓	✓	⊘	👤
<b>TCM - TRANSMISSION CONTROL MODULE</b>				
Sistema	DTC	Flujo de Datos	Actuadores	Config
TCM - GALAXY/SMAX	✓	✓	⊘	⊘
TCM FIESTA / MAZDA	✓	✓	⊘	👤
TCM TRANSIT	✓	✓	✓	👤
<b>TPM - TYRE PRESSURE MONITOR</b>				
Sistema	DTC	Flujo de Datos	Actuadores	Config
TPM MOUNTAINEER/EXPLORER	✓	👤	✓	⊘
<b>TRM - TRAILER MODULE</b>				
Sistema	DTC	Flujo de Datos	Actuadores	Config
TRM - GALAXY/SMAX/MONDEO MY08	✓	✓	⊘	⊘
<b>VDM - VEHICLE DYNAMICS MODULE</b>				
Sistema	DTC	Flujo de Datos	Actuadores	Config
VDM - GALAXY/SMAX/MONDEO MY08	✓	✓	⊘	⊘