

WIN-STAR Diagnostic system Function List-----Mitsubishi

UPDATE 2005/09/15



WIN-STAR kit, including of :

1. Multiplexer box.
2. Cables, including of :
 - a. RS232 Cable (from PC or Notebook to multiplexer box)
 - b. 16 PIN cable (from multiplexer box to vehicle)
 - c. 12 PIN cable (from multiplexer box to vehicle)
 - d. 12 PIN cable (from multiplexer box to vehicle)
3. Instruction manual.
4. Suit case.

Sale version : MIT-S1

Software version : MI

System	Function				REMARK
ECU	Read DTC	Erase DTC	Live data	Actuation	
MPI/GDI/DIESEL	v	v	v		<p>For perfect performance of WIN-STAR or MAGUS PC-based Automotive Diagnosis, please confirm PC/Laptop you or your clients select must follow the requirement below.</p> <p>PC/Laptop Requirements:</p> <ol style="list-style-type: none"> 1. 1~2.8G Hz To exceed this limitation is not allowed. 2. RAM: 512MB 3. HD: 1G (free capacity at least) 4. Computer: it is better to use the computer with RS232 port. In case without it, please use a USB-RS232 converter. (USB Converter can be purchased from I.C.M. company now) 5. Operation System: WINDOW 2000 or WINDOW XP only
IMMOBILIZER	v	v	v		
ELC-AT/CVT	v	v	v		
SS4 II	v	v	v		
ECS	v	v	v		
FULL AUTO A/C	v	v	v		
TCL	v	v	v		
ABS/ASC	v	v	v		
HBB	v	v	X		
AYC	v	v	v		
AUTO CRUISE	v	v	v		
4WS	v	v	v		
SRS-AIR BAG	v	v	v		
VARICA	v	v	v		