

2007 Toyota Hilux Timing Belt Light Reset

3.0L 1KD Diesel Engine

The timing belt light displayed on the dash on a 2007 Toyota Hilux diesel is reset using the following manual procedure.

- Turn ignition on.
- Make sure the Odometer/Trip meter display shows odometer information.
- Turn ignition switch off.
- Press and hold the odometer/trip display button whilst turning ignition on.
- Hold button down for 5 seconds then release button.
- Within 5 seconds, press and release the button.
- The display will show the reset value.
- Press and hold the odometer/trip button for 5 seconds then release button.
- Make sure the odometer reading is displayed and the warning lamp has gone out.