



**** To complete this function you will require 2 or more keys!!**


1. Select PATS




2. Select Ignition keys erase




3. Notice




4. Notice



5. Notice



6. The 'out code' is displayed.



** To proceed you will need to know the 'incode'. This code is obtained from a FORD dealer.

7. Input the incode

▶ PATS(Passive anti theft system) > Ignition keys erase

Incode :

4527

KEYBOARD

0	1	2
3	4	5
6	7	8
9	A	B
C	D	E
F	<-	Enter

OK CANCEL

Copyright
G-Scan Oceania

8. G-scan will erase all keys.