

## HOLDEN ISUZU EARLY MODEL 4 WD RESET PROCEDURE

Remove the driver's seat.

1. Prepare 2 pieces of wire with paper clips or similar at each end.
  2. Ignition off.
  3. Keep connectors connected to transfer controller - (it is easier to get the wires in the connectors if you unbolt the controller from the floor. If it has been reset before, the carpet may have already been cut, which makes it easier to get to the bolts and the connectors.)
  4. Fit one wire into terminal 10 of the larger connector and terminal 16 of the smaller connector - (there is no wire in connector 16, just feed the paper clip into the hole until it touches the pin in the controller)
- Fit the other wire in terminal 9 of the small connector and terminal 15.  
(Terminal 15 has no wire in it - same as terminal 16)
5. Turn the ignition on. The Check 4WD light should now go out. If not check all wires for good connection or there is another problem.
  6. Turn the ignition off. Remove the wires. Turn the ignition on to check to see if the check 4WD light stays off.

Terminal 10 is in the top left of the large connector.

Terminal 16 is in the bottom left of the small connector.

Terminal 9 is in the bottom right of the small connector.

Terminal 15 is in the second space from the left on the bottom of the small connector.

All directions are when looking at the back of the connectors (wire side)