



1. Select Astra-G immobilizer



2. Select special function



3. Select Reset immobilizer



4. Input security code

Immobiliser > Reset Immobilizer

Input security code(4-digit number) :

1	2	3
4	5	6
7	8	9
0	Enter	

OK No

Copy right
G-Scan Oceania

5. Notice

Immobiliser > Reset Immobilizer

Note :

- See checking procedure before programming.

Press [OK] to next.

OK No

Copy right
G-Scan Oceania

6. Notice

Immobiliser > Reset Immobilizer

Warning!!

- Engine will not start after reset.
- Do this only before replacing the immobilizer ECU.

Press [OK] to next.

OK No

Copy right
G-Scan Oceania

7. Ignition off



8. Ignition on

