




1. Select CDID2 engine.




2. Select special function.



3. Select Reset fill factor of air filter



4. Information



5. Preconditions



6. Turn IG. Off



7. Turn IG. On.

