




1. Select CDID2 engine.




2. Select special function.




3. Select Adjustment of injector injection quantities




4. Information




5. Information




6. Programmed injector codes.



7. Input new code.



8. Turn IG. Off.



9. Turn IG. On.

