



**** Caution!! This function will erase every programmed keys.**


1. Select the Cruze > Engine type > Body > Immobilizer




2. Select the [Special function]




3. Select the [Key programming]




4. Notice.



7. Notice




8. Notice







9. Press button.




10. Deleted all keys.




11. Insert key.



12. Complete.



13. Notice



14. Notice



15. All procedure complete.

