


1. Select Canter Euro5 Engine



2. Select Special function



3. Select Reset of oil monitoring



4. Notice



5. Notice.

