




1. Select BCM(Body control module)



2. Select special function



3. Select brake pedal position sensor learn



4. Preconditions

