



1. Select IPC(Instrument cluster)




2. Select special function



3. Select CAN Bus configuration learn



4. Notice



5. Turn IG. On



6. Turn IG. Off



7. Turn IG. On

