


1. Select [New Focus] menu

** Whether the Focus is "Diesel" or "Petrol", the ABS Special functions are the same.




2. Select [Special function]




3. Select [Configure the longitudinal acceleration sensor]



4. Notice



5. Notice



6. Notice

