




1. Select [Anti theft warning]



2. Select special function



3. Select erase remote keys



4. Input security number

▶ Anti theft warning > Erase remote keys

Erase all remote keys.
Do you wish to continue?

4562

1	2	3
4	5	6
7	8	9
0	Enter	

OK No

Copy right
G-Scan Oceania

** Before the programming, you must confirm that code is correct.

5. Note

▶ Anti theft warning > Erase remote keys

Erase all transponder keys.
Do you wish to continue?

OK No

Copy right
G-Scan Oceania