

MAE Support document VW/AUDI

BASIC SETTING FOR VW/AUDI FOR IDLE-THROTTLE VALVE RELEARN

AUDI VW

*****KOEO: Key On Engine Off*****

1. Channel Number of basic setting for VW/AUDI car models

===Preconditions of Basic Setting===

- The engine must reach the working temperature
Note: Engine Coolant temperature must be higher than 80°C
- Turn off the accessorial electrical appliances, e.g. headlights, air conditioner etc.
- Ensure there is no fault code in memory for engine system
- The throttle is fully closed, and the brake pedal is released, with manual transmission in neutral position - automatic transmission in park position

Channel Number	Basic Setting	Engine Status	Car Model
000	Engine basic parameter	Idle speed running	Audi / VW
001	Idle speed control valve N71	Engine not running	Audi / VW
002	Control self adaptation	Idle speed running	Audi / VW
098	Throttle valve J338	Idle speed running	Audi / VW
060	Throttle valve J338	Idle speed running	Audi / VW

Operation for Basic Setting:

Select the **ENGINE** in the menu, then go **BASIC SETTING**, and then enter the channel number based on the list provided as above. Press enter to confirm, check live data ADPT-RUNS and after approximately 10-15 seconds ADPT-OK. Function is now complete.