




1. Select correct system




2. Select [Special function].



3. Select [Remote vehicle start disable history reset].



4. Note.



5. Complete.

