


**** Caution!!** Before this function be performed,
place the vehicle on a flat level surface and remove all excess weight.

**** Caution!!** After this functions, please keep idle running until ABS lamp turned off.
(Approx. 5 min)

1. Select correct system




2. Select [Special function].



3. Select [Yaw rate sensor learn].



4. Note.



5. Complete.

