




## Type 1

300 / Charger / Durango / Cherokee / Grand Cherokee / Magnum






\*\* Please follow the instructions that have been exposed.




\*\* After executing the function, starting the traveling of the vehicle, the value goes up from 0 to 100%.


\*\* However, if more than 5 minutes driving car even if the value does not change, please perform the function again from the beginning.




## Type 2

200/Dart





\*\* Please follow the instructions that have been exposed.



\*\* After executing the function, starting the traveling of the vehicle, the value goes up from 0 to 100%.

\*\* However, if more than 5 minutes driving car even if the value does not change, please perform the function again from the beginning.

