



**** Caution!! This function will erase any programmed keys.**

1. Select the SSANGYONG REXTON > IMMOBILIZER > DIESEL


2. Select the [Special function]




3. Select the [Key Coding]




4. INPUT VIN Number




5. Notice > 1st Key Input




6. Notice > 1st Key Coding OK



7. Notice > 2nd Key Input




8. Notice > 2nd Key Coding OK




1. Select the REXTON > IMMOBILIZER > GASOLINE


2. Select the [Special function]




3. Select the [Key Coding]




4. Notice




5. Notice



6. Notice



7. Notice > Result message



8. Notice

