




1. Select diesel engine




2. Select [Special function]



3. Select the [Fuel injector learn]




4. Check the precondition



5. Starting learning.



6. Turn ignition off



** G-scan wait 15s for the learning

7. Turn ignition on

