



1. Select the 4JJ1-TC



2. Select the [Special function]




3. Select [DPD status resetting]



4. Press [OK] to continue




5. Turn ignition off



**\*\* After pressing the [OK] button, wait about 5 seconds for resetting to complete.**

6. Turn ignition on



7. Complete.

