## RA Rodeo Remote Control Programming 2006-2008

Note: A maximum of 4 remote transmitters can be programmed to the Keyless Entry control unit memory. If the number exceeds 4, then the oldest one will be erased.

- 1. Close doors and leave unlocked. Insert key into ignition switch.
- 2. Open the drivers door.
- 3. Turn the key to the ON position then to the Lock position three times within 5 seconds.
- 4. Within 5 seconds close and open the drivers door once (leaving the drivers door in the Open position.
- 5. Wait for 8 seconds. (This must be done)
- 6. Turn the ignition key to ON then to LOCK position and leave in the lock position.
- 7. Close the drivers door. The hazard lights should flash three times. (The system has entered programming mode)
- 8. Operate the Unlock button of the transmitters to be programmed 3-4 times. The hazard lights will flash to indicate the remote has been successfully programmed.
- 9. The hazard lights will flash approximately after 4 seconds after pressing the remote button to indicate the system has exited programming mode.