



**** This function is supported within the [Entry and start] System.**


1. Select the [Key code erasure] function.




2. Notice



3. Programmed key number.



4. Touch IG switch with the already programmed key within 30s.



5. Complete.

