



1. Select [ASM] system




2. Select [Special function]



3. Select [Learn clutch parameter]



#### 4. Preconditions



#### 5. Select [N] gear.

