



Total Diagnostic Solutions



Exceed Your Expectations

Trade Show

AMR 2011 - Auto Maintenance & Repair

March 16 - March 19, 2011

New China International Exhibition Center (NCIEC), Beijing, China

Automechanika Malaysia

Malaysia International Trade Fair for Automotive Parts, Equipment & Service Suppliers

March 31 - April 2, 2011

Kuala Lumpur Convention Centre, Kuala Lumpur, Malaysia

TAIPEI AMPA 2011

Taipei Int'l Auto Parts & Accessories Show

TWTC Nangang Exhibition Hall, Taipei, Taiwan

We look forward to greeting you there!

iSCAN-II / D91 Latest Versions (November, 2010)

iSCAN-II TOYOTA	V3.02 / V2.04 / V1.04	English/Chinese/Japanese	2010-11-01
iSCAN-II IMS2-VASS	V1.02	English/Chinese	2010-11-01
iSCAN-II BMW	V3.02 / V2.03 / V1.09	English/Chinese/Japanese/Korean	2010-11-04
IMS2-MB Add-On	V4.02	English/Chinese	2010-11-16
iSCAN-II HONDA	V2.02 SP2	English/Chinese/Japanese	2010-11-17
iSCAN-II LANDROVER	V3.01	English/Chinese/Japanese	2010-11-23
iSCAN-II PORSCHE	V3.02 / V2.05 / V1.05	English/Chinese/Japanese	2010-11-23
iSCAN-II NISSAN	V3.01 / V2.04 / V1.08	English/Chinese/Japanese/Spanish	2010-11-23
iSCAN-II IMS2-PORSCHE	V1.03	English/Chinese	2010-11-23
iSCAN-II CHRYSLER	V3.06	English/Chinese	2010-11-23
D91-TOYOTA	V5.04 / V4.54	English/Chinese/Japanese	2010-11-01
D91-HONDA	V3.02 SP2	English/Chinese/Japanese	2010-11-17
D91-NISSAN	V5.04 / V4.08 / V3.59 SP1	English/Chinese/Japanese/Spanish	2010-11-23
D91-PORSCHE	V4.55 / V4.05	English/Chinese/Japanese	2010-11-23

VeDiS Yearly Update Project (YUP) Software

Software releases monthly for D91-EURO PRO YUP 2010 / D91-ASIAN PRO YUP 2010.

YUP customers, please get the updates from website.

Technical Guidance

BMW CKM (Car & Key Memory) Options

Introduction

The function of BMW CKM (Car & Key Memory) is to set the personal preferences for the car owner. Before model E90, the preferences are set via car memory or key memory. After model E90, most preferences are set on the key memory. Depending on the personal preferences, every key is allowed to memorize its exclusive settings.

BMW Car / Key memory is available on the earlier models (E38 / E39 / E46 / E53 / E83) and the later models (E65 / E66 / E60 / E63). The car / key memory can be set via iSCAN-II BMW CODING / SSS software. After E90, the setting is not done via the diagnostic scanner. The car owner can change the setting by himself to press BC button or iDrive controller.

CKM available Models

MODELS	How to set CKM	CKM	Supported Items
E38, E39, E46 E53, E83, E85, R50, R52, R53	BMW CODING on iSCAN-II	Car Memory & Key Memory	Lighting, KOMBI, Mirror, Seat, Heating, Air Condition...
E65, E66, E60, E61, E63, E64	1. BMW SSS on iSCAN-II 2. Lighting & Central Locking on iDrive	Car Memory & Key Memory	Anti-theft, Central Locking, Exterior Lighting, Interior Lighting, Windows/ Sunroof, Heating / Air Conditioning, Ventilation...
E90, E91, E92, E70, E71, F01, F02, F10	iDrive, BC Button, By Manual	Key Memory	Anti-theft, Central Locking, Exterior Lighting, Interior Lighting... (depends on the equipped items)


Example 1: BMW E60 CKM on iSCAN-II

Example 2: BMW E90, BC button

Example 3: BMW E90, iDrive controller

Procedures on iSCAN-II:


1. Select **Vehicle Diagnostic** -> select **EUROPEAN**





2. Select **BMW GT2**, then select **BMW SSS** software



3. Select **CKM Car/Key Memory**, then press ENTER to continue




4. Press ENTER to continue



5. Select **E60/E61**, then select **BURGLAR ALARM SYSTEM**




6. Enter the setting page, press the number to set it active or not active.




7. After setting, please EXIT to continue.

Follow the information to turn the ignition OFF for 30 seconds, then turn ignition ON.

Check the situation if it is okay.





Example 2: BMW E90 (BC button)

1. CKM Set Menu

- (1) Insert the key to turn the ignition ON
- (2) Use the toggle switch on indicator stalk to scroll up/down to the Set menu
- (3) Press the BC button to access the sub menu



2. Flash when unlocking:

Via turn signal flickering, it is to confirm the function activated when unlocking.

Set the item from one of the follows:

- (1) Function activated: flash when unlocking
- (2) Function deactivated

Operation:

- (1) Scroll up/down the toggle switch to the image shown as following.
- (2) Press the BC button to access the menu, then scroll up/down to select the setting. Press the BC button again to save the setting.



3. Flash when locking:


Via turn signal flickering, it is to confirm the function activated when locking.

Set the item from one of the follows:

- (1) Function activated: flash when locking
- (2) Function deactivated

Operation:

- (1) Scroll up/down the toggle switch to the image shown as following.
- (2) Press the BC button to access the menu, then scroll up/down to select the setting. Press the BC button again to save the setting.



4. Unlock door locks:

The settings of unlocking the doors when using the remote.

Set the item from one of the follows:

- (1) Press the unlock button on remote once, unlock all the doors
- (2) Press the unlock button once to unlock the driver's door only; press the unlock button twice to unlock all the doors.

Operation:

- (1) Scroll up/down the toggle switch to the image shown as following.
- (2) Press the BC button to access the menu, then scroll up/down to select the setting. Press the BC button again to save the setting.



5. Central Locking Setting:

It is to set the conditions when the central lock will activate automatically.

Set the item from one of the follows:

- (1) Relock the door if not opened
- (2) Relock the door if not opened or after starting the engine
- (3) Keep unlocking condition

Operation:

- (1) Scroll up/down the toggle switch to the image shown as following
- (2) Press the BC button to access the menu, then scroll up/down to select the setting. Press the BC button again to save the setting.



6. Pathway lighting:

It is to have the pathway lighting for a few seconds after the car is locked.

Set the item from one of the follows:

- (1) Activate the pathway lighting for 10 ~ 240 seconds
- (2) Function deactivated

Operation:

- (1) Scroll up/down the toggle switch to the image shown as following.
- (2) Press the BC button to access the menu, then scroll up/down to select the setting. Press the BC button again to save the setting.



7. Daytime running lights:

Automatically switch on the low-beam headlamps or automatic running lamps when the vehicle is moving forward.

Set the item from one of the follows:

- (1) Function activated
- (2) Function deactivated

Operation:

- (1) Scroll up/down the toggle switch to the image shown as following.
- (2) Press the BC button to access the menu, then scroll up/down to select the setting. Press the BC button again to save the setting.



8. Flickering times of turn signals:

It is to set the flickering times of turn signal when gently press the turn signal lever.

Set the item from one of the follows:

- (1) Flicker once
- (2) Flicker thrice (3 times)

Operation:

- (1) Scroll up/down the toggle switch to the image shown as following.
- (2) Press the BC button to access the menu, then scroll up/down to select the setting. Press the BC button again to save the setting.



9. Automatically adjust the positions of driver's seat & back mirror:
After the driver adjust his own positions setting on the driver's seat & back mirror, the position setting will be memorized on his current remote.

Set the item from one of the follows:

- (1) Function activated when the central lock is activated
- (2) Function activated when the driver's door is opened
- (3) Function deactivated

Operation:

- (1) Scroll up/down the toggle switch to the image shown as following.
- (2) Press the BC button to access the menu, then scroll up/down to select the setting. Press the BC button again to save the setting.



Example 3: BMW E90 (iDrive controller)

1. Vehicle Settings:

- (1) Insert the key to turn the ignition ON
- (2) Press iDrive controller down to access the menu
- (3) Enter i menu
- (4) Press the iDrive controller to select the Vehicle settings



2. Lighting Settings: enter the Lighting menu to change the settings

- (1) Pathway lighting
- (2) Auto. headlamps
- (3) Triple turn signal activation
- (4) Daytime running light

Operation:

- (1) Rotate iDrive controller to access the sub-menu.
- (2) Press iDrive controller down, rotate and press the controller to display/change the settings.



3. Door locks Settings: enter the Door Locks menu to change the settings.

* Central Locking

- (1) Unlock button (Drive's door only)
- (2) Last seat pos. (Deactivated)
- (3) Relock door if not opened
- (4) Lock after driving

* Confirmation

- (1) Flash when locking
- (2) Flash when unlocking

Operation:

- (1) Rotate iDrive controller to access the sub-menu.
- (2) Press iDrive controller down, rotate and press the controller to display/change the settings.



CopyRight 2008 AUTOLAND SCIENTECH Co., Ltd All Rights Reserved 
Any questions, please contact sales@autolandscientech.com.

www.autolandscientech.com