

No.

AUTOLAND ePaper

Total Diagnostic Solutions / Exceed Your Expectations

Trade Show

2015 Automechanika Dubai

EXHIBITION DATES : JUNE 02 - JUNE 04, 2015 Dubai International Convention and Exhibition Centre Booth Number: SR-325

MYANAUTO 2015

EXHIBITION DATES : OCTOBER 09 - OCTOBER 11, 2015 Myanmar Event Park, Yangon, Myanmar Booth Number: Coming soon

We look forward to greeting you there!

Latest Versions (May, 2015)

Software	Version	Language	Release date
MAZDA OBDII	2013.12/2012.12	USEN/TWCH	2015/3/19
FORD	2013.12SP1/2012.12SP1	USEN/TWCH/MXSP	2015/3/19
IMS2-BMW-2(ICOM)	V2.07	USEN/TWCH	2015/3/19
NISSAN	2015.02/2014.12/2013.12SP3	USEN/TWCH/JPJP/MXSP	2015/4/7
VOLVO	2015.03/2014.12	USEN/TWCH/JPJP	2015/4/7
MITSUBISHI	2015.02/2014.12 /2013.12SP4	USEN/TWCH/JPJP	2015/4/10
FORD Programming	2015.03	USEN/TWCH	2015/4/10
MAZDA Programming	2015.03	USEN/TWCH	2015/4/10
GMSA	2015.03	USEN	2015/4/10
MB	2014.12SP2/2013.12SP5/2012.12SP5	USEN/TWCH/JPJP	2015/4/17
BMW SSS	2015.04/2014.12	USEN/TWCH	2015/4/24
BMW Programming	2015.04/2014.12/2013.12SP4	USEN/TWCH	2015/4/27
BMW F-CIP	2015.04/2014.12/2013.12SP3	USEN/TWCH	2015/4/27
BMW Encoding Database	2015.04		2015/4/27
GMNA	2015.04	USEN/TWCH	2015/4/27
HOLDEN	2015.04	USEN	2015/4/27

Yearly Update Project (YUP) Software

Software release monthly for: iScan-IIwt /VeDiS-II EURO PRO YUP 2015 iScan-IIwt /VeDiS-II ASIAN PRO YUP 2015 Please get the updates from website.

Technical Guidance Mercedes -Benz EPB (Electronic parking brake) When to perform this function: When the brake pad is replaced. When the rear brake caliper is replaced. Prerequisites (before performing this function): Park the vehicle on a level surface. Turn on ignition. Release the hand brake(hand brake indication light goes off). Note: The following models are equipped with electronic hand brake: W222 \winter W166 \winter W218 \winter W246 \winter W205.

How to perform this function utilizing iScan-II wt

Example: BENZ ML350 W166

1. Select Vehicle Diagnostic -> EUROPEAN

1	2
Main Menu –	Vehicle Diagnostic
1 Vehicle Diagnostic	
2 Component Test System	
(External Modules)	
3 IMS2 (Interface Module	1 EUROPEAN
Simulation System)	2 ASIAN
80 OBD-II Standard Compliant	3 USA>
Diagnostics	4 AUSTALIA
81 J2534(passthru)	
82 DOL Mode (Diagnostic On-Line)	
90 Printing Manager	

2. Select MERCEDES-BENZ PKG \rightarrow MB

3	4
EUROPEAN ↓"	MERCEDES-BENZ PKG
1 FORD PKG 2 PORSCHE PKG 3 BMW PKG 4 LAND ROVER PKG 5 OPEL VAUXHALL 6 FIAT LANCUA ALFA 7 VW AUDI SEAT SKODA 8 MERCEDES-BENZ PKG	1 MB 2014.12SP1 USEN 2 MB Coding 2014.12SP1 USEN

3. Select M-Class



4. Select 166 -> Individual System Search



5. Select Chassis System -->EPB-Electronic parking brake

8	9
M-Class 166 1 Power Train System 2 Chassis System 3 Body System 4 Air Conditioning System 5 Information and Communication System 6 Seats and doors	Chassis SystemI1 ESP-Electric stability program2 EPB [EFB]-Electronic parking brake3 AIRmatic4 ES-Electrical power steering5 TPC-Tire pressure monitor6 DTR-Distronic7 ROLL-Roll control8 EGW-Chassis gateway



7. Select Move to the assembly position



8. Please make sure the status of both sides electronic parking brake are OPEN (EPB is off)



9. When both sides of the actuator status are in the assembly position, then you can begin repair work.



Move to the assembly position

Status of associated actual values Status of left electric parking brake Brake IS RELEASED Status of right electric parking brake Brake IS RELEASED

1 Move to the assembly position 2 Deactivate assembly position Move to the assembly position

Status of associated actual values Status of left electric parking brake IN ASSEMBLY POSITION Status of right electric parking brake IN ASSEMBLY POSITION

1 Move to the assembly position 2 Deactivate assembly position

After entering the maintenance mode,

the parking LED of instrutment will lit as shown below:



10. After the repair is completed, select Deactivate assembly position.

18 Move to the assembly position Status of associated actual values Status of left electric parking brake IN ASSEMBLY POSITION Status of right electric parking brake IN ASSEMBLY POSITION 1 Move to the assembly position 2 Deactivate assembly position	19 Move to the assembly position Deactivate assembly position. Please wait

11. When both sides of the actuator status are OPEN, exit from the maintenance mode





Any questions, please contact sales@autolandscientech.com.

www.autolandscientech.com