



1. Select [International] > [Passenger car] > [ALL MODEL] > [ALL TYPE]
> [16PIN CONNECTOR] > [AYC(Active yaw control)/ACD]




2. Select [Special function] - Lancer evolution X



** If the vehicle is not a Lancer evolution X, the Bleeding function is found in [Actuation]




3. Select [Air bleeding]



4. Select [F1 : 1 ACD Air bleeding]



5. Press [OK] to start.



** After the function starts, the G-scan will display the progress status.